



Advantages on E302 Water Distiller:

1. Has an ON/OFF switch button, no need unplug the power code to stop the machine.
2. Has a Fuse Holder with 2XF10A, it has a safety short-circuit integration that complies with the European Electrical Safety Standard.
3. Manual-type 110 degree Thermostat from USA Emerson Electric Co. This kind of thermostat is more precise than most brands, it makes the distillation water purer and fresher (never burns the water). It is the best choice for Dental/Medical/Home/Beauty/Food use etc.
4. Has an good structure with a fixed Emerson Thermostat to make sure the unit operates precisely and never lose control.
5. Has a 300-degree automatically-type thermostat. Will cut off the power when overheating.
6. Has a re-set button to ensure the machine has a long lifespan.
7. Has a heating element that is fixed on the water tank by screws which make the after-service more economical and energy saving.
8. The whole machine power is 800 W, unit delivers 4L of distilled water within 3.75 hours

